

8010 AFX Gorden Bar Location

Rows counting from the front to the rear.

Rows	Quantity and type of Bars
1	Leave four specialty bars on very front four pedestals.
2 & 4	Connect four Gorden Bars between rows two and four
3 & 5	Connect four Gorden Bars between rows three and five
6 & 8	Connect two Gorden Bars between rows six and eight Note: If bar does not match pedestal spacing, turn rotor 1/4 turn and then it will. Then turn 1/2 turn and put second bar on opposite side.
7 & 9	Connect four Gorden Bars between rows seven and nine
10 & 12	Connect two Gorden Bars between rows ten and twelve Note: If bar does not match pedestal spacing, turn rotor 1/4 turn and then it will. Then turn 1/2 turn and put second bar on opposite side.